

How to Assemble Your Blind Wall Corner Cabinets

Before you start to assemble your cabinet, please make sure that all of the following parts are included in the carton. In case of any shortage, please contact the dealer and request the delivery of the missing part.

A – Door Faceframe (1)

B – Side Panels (2)

C – Bottom Panel (1)

D – Top Panel (1)

E – Back Panel (1)

F – Large Face Board (1)

G – Optional Filler (1)

I – Shelves (2)

H – Hardware Bag (1); Shelf Holders – 8, Small Silver Screw – 6, Largest Black Screw – 6, Small Black Screw – 8

Please use the following steps to begin assembly:

1. Take out all of the parts from the carton and carefully lay the Door Faceframe (A) with finished side downwards onto a soft and flat surface so that it will not be scratched.
2. Two Side Panels (B) are to be positioned into the grooves on Faceframe (A). Align the metal connectors and press downward until the half sections of the metal connectors on the Door Faceframe (A) fit properly into the mates on the Side Panels (B). For best results, place a screw into the metal sliders after locked into place.
3. Insert Top (D) and Bottom (C) into the grooves of Side Panels (B) in order to seat and align Top (D) and Bottom (C) panels. Please note that you will have to gently spread Side Panels (B) in order to seat and align Top (D) and Bottom (C) panels. Make sure that all is in place as in step 2.
4. Slide Back Panel (E) into groove in rear of Side Panels (B). Make sure finished side of panel is to the inside of the cabinet. Once the Back Panel (E) is aligned and all is in place, insert the small screws provided in the Hardware Bag (H) into the pre-drilled holes in Back Panel (E) and tighten securely.