

6. After mounting the cabinet to the wall, insert the Shelf Holders from the Hardware Pack (F) into the holes in the cabinet at the desired height and slide in shelves (G).

Your Corner Wall Cabinet is Complete!

