

into the grooves of Drawer Sides (b), position Drawer Back (C).

- g. Slide left and right Drawer Slides (G) into Drawer Slide Holders. Position left Drawer Slide Assembly and fasten with small screws. First into pre-drilled hole on Faceframe(A), then slide Holder back flush with rear of cabinet and Align with holes (3). Repeat these steps for the right Slide.
- h. After mounting the cabinet to the wall, insert Shelf Holders from the Hardware Bag (F) into the holes in the cabinet at the desired height and slide in Shelf (C).

Your Base Cabinet is Complete!

