

Hinge center in case of
PIANO/BUTT HINGE

Door edge
CONCEALED HINGE

$1 \frac{1}{8}''$

*5 $\frac{1}{4}''$ from
top of inside
of cabinet*

Soft-close

Speed
adjustment screw

